



# WATER & AIR

## Instructions for fitting radiation screen to RH/Temperature probe

1. Remove base of probe
2. Unscrew the four stainless steel screws located in the four pillars of the screen.
3. With the screen standing on its four dome nuts, locate the extension part of the probe in the central holes with housing resting on the four pillars.
4. The four stainless steel screws screw the box to the four pillars from the inside of the box. Holes in the box line up with these pillars.
5. Screw up firmly without over-tightening
6. Replace base of the probe

